



Safety notice

The barrier must be inspected frequently to spot all wear, corrosion or crack being able to cause damage, especially if the barrier has an excessive duty service (frequent opening before the end of the closing cycle).

If the barrier is damaged or hit, it must be inspected by competent personnel to spot all damages or cracks.

The barrier and the fence must be cleaned of all ice or snow accumulation to avoid increasing the load.

No object (light, sign etc.) must be added to the barrier.

The fence must not be modified without the authorization of Automatic Systems America Inc.

The barrier must be put out of service if cracks appear or if the safety of the people is compromised.

| REV. | DATE | MODIFICATIONS/CHANGES | PAR/BY |
|-----------|------------|--|---------|
| E | 2017-06-21 | CHANGE OF ARM SEGMENTS LENGTH AND POSITION | PLA/SSA |
| D | 2015-08-17 | ALTERATION TO SAFETY NOTICE | ACS |
| C | 2012/08/14 | GENERAL NOTE ADDED AND WALL SPECIFICATION | JPS |
| B | 2009/02/27 | DRAWING CORRECTION OF THE FENCE REPRESENTATION | PYM |
| REVISIONS | | | |

NOTES:

1- AUTOMATIC SYSTEMS RECOMMENDS THAT THE CONCRETE BASE FOR THE BARRIER BE FABRICATED ACCORDING TO DRAWING "1164-2007-2008_TYPICAL BLG76 CONCRETE BASE". HOWEVER IT IS THE CUSTOMER'S RESPONSIBILITY TO ENSURE THAT THE INSTALLATION CONFORMS TO ALL LOCAL BUILDING CODES.

2- FOR CONDUIT LAYOUT REFER TO NAM-BL5X-BLG76-CONDUITS-IN-EN.

| | | |
|--|--------------|-------------|
| MATERIAU/MATERIAL | | |
| N/A | | |
| FABRICATION | | |
| N/A | | |
| TRAITEMENT/TREATMENT | | FINI/FINISH |
| N/A | | N/A |
| Nb./App. | POIDS/WEIGHT | SURFACE |
| - | - Lbs | - in2 |
| LES INFORMATIONS CONTENUES SUR LES DESSINS DE ASA Inc. SONT CONFIDENTIELLES ET SONT LA PROPRIÉTÉ DE ASA Inc. TOUTES REPRODUCTIONS, DISTRIBUTIONS OU UTILISATIONS SONT INTERDITES SANS LA PERMISSION ÉCRITE DE ASA Inc. | | |
| INFORMATION DISCLOSED HERE IS CONFIDENTIAL AND IS THE PROPERTY OF ASA Inc. ANY REPRODUCTION, DISTRIBUTION OR USE IS PROHIBITED WITHOUT A WRITTEN CONSENT BY ASA Inc. | | |
| SIMILAR PARTS | | |

| | |
|---|-----------------|
| FICHER FILENAME | 1170-37-L002 EN |
| EBARBER & ENLEVER LES ARÊTES VIVES BREAK ALL SHARP EDGES AND CORNERS | |

| | |
|---|---------|
| LES DIMENSIONS SONT EN POUÇES. DIMENSIONS ARE IN INCHES | |
| TOLERANCES | |
| .XXXX | ± .0005 |
| .XXX | ± .005 |
| .XX | ± .01 |
| FRACT. | ± 1/64 |
| ANGLES | ± 1/2 ° |
| SAUF SI INDIQUÉS UNLESS OTHERWISE NOTED | |

| | |
|--|------------------------------|
| automatic systems america inc. | |
| TITRE | BLG76 5m LEFT |
| TITRE | Dimensions and Safety Notice |
| DESSINÉ PAR DRAWN BY | GG |
| ECHELLE/SCALE | N/A |
| DATE | Oct 2, 2006 |
| FEUILLE/SHEET | 1 |
| DE/OF | 1 |
| VÉRIFIÉ PAR CHECKED BY | AG |
| NO. DE DESSIN/DWG. NO. | 1170-37-L002 EN |
| REV. | E |