

Safety notice

The barrier must be inspected frequently to spot all wear, corrosion or crack being able to cause damage, especially if the barrier has an excessive duty service (frequent opening before the end of the closing cycle).

If the barrier is damaged or hit, it must be inspected by competent personnel to spot all damages or cracks.

The barrier and the fence must be cleaned of all ice accumulation or of snow to avoid the load increase.

No object (light, sign etc.) must be added to the barrier.

The fence must not be modified without authorization of Automatic Systems America Inc.

The barrier must be put out of service if cracks appear or if the safety of the people is compromised.

r						
	G	April 8th,08	New notes on side		A	١G
	F	Mar 05, 08	Notes about perimeter fence		P	PYM
	E	Dec 12, 07	24in between fence and operate	pr	A	١G
	I	2017-06-28	MODIFICATION OF ARM LENG	GTH	PLA	/SSA
	н	2012-08-14	GENERAL NOTE ADDED AND	WALL SPECIFICATION	J	PS
RÊTES VIVES	REV.	DATE	MODIFICAT	IONS/CHANGES	PAF	R/BY
ND CORNERS	REVISIONS					
S aut syst	ten	ns a	merio	ca ind	.	
		RIGHT and Safe	ety Notice			
NÉ PAR N BY AG	échelle N/A	/SCALE	DATE Oct 2, 2006	FEUILLE/SHEET	DE/OF	1
é par Ked by AG	NO. DE I	DESSIN/DWG. N	^{ю.} 1170-37	′-L001 EN ^R	REV.	